


Installation and User Instructions



Model: E118S Fireplace Mantel

For use with E119R – 2kW Electric Fire


**PLEASE READ THIS MANUAL BEFORE INSTALLING AND USING APPLIANCE.
INSTALLER: DO NOT DISCARD THIS MANUAL – LEAVE WITH THE CUSTOMER.
SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

Appliance Development Services Ltd

Tel 01723 583227

SECTION 1 DIMENSIONS


Dimensions in mm



SECTION 2 ASSEMBLY AND INSTALLATION

2.1 Unpack

- Open the package carefully and remove all pieces. Carefully inspect each part for any damage before you begin assembly.
- Make sure that you have all the parts listed below before assembling.




No.	Name	Quantity
A	Top panel	1
B	Front top panel	1
C	second top panel	1
D	Front bottom panel	1
E	Base panel	1
F	leg side panel	2
G	left leg front panel	1
H	left leg second panel	1
I	fire support panel	2
J	Right leg second panel	1
K	right leg front panel	1
L	M6X12 screws 	37
M	M6X30 screws 	18
N	Φ8x30 dowels 	13
O	washers 	18
P	Small L bracket 	17
Q	Flat bracket 	3
R	Rubber feet 	6

NOTE: left and right of product are distinguished by its front view.

2.2 Before installation

Tools required: magnetic Philips screwdriver.




2.3 Installation


NOTE!

- Assembly required by two adults.
- This fireplace suite must be fitted to the wall. Wall fixings are supplied with this mantel, but any other suitable concealed fixing may be used.
- Use manual screwdriver only.
- Use washer when fixing with screws. Do not overtighten bolts.
- Do not use other types or models of screw, to prevent any screws that are too long causing damage to mantels.
- To prevent scratching the mantel, only fit the fire from the back of the fireplace .


Step 1:




Step 2:




Step 3:




Step 4:




Step 5:




Step 6:




Step 7:




Step 8:




Step 9:




Step 10:



Step 11:



Step 12:



SECTION 3 CLEANING & MAINTAINENCE

- 1 Your fireplace mantel surface coating will give off a slight smell for a short period of time. Try to ventilate as much as possible during this time.
- 2 Daily cleaning: Clean the mantel surfaces with a soft, lint-free cloth. Do not use cleaning or polishing products and try to avoid heavy or sharp articles which may damage the surface.
- 3 Avoid long-term direct sunlight, and excessive temperatures and humidity to protect the life of your furniture surface.

Appliance Development Services Ltd

Bakers Court, Hopper Hill Road, Scarborough, N. Yorkshire. YO11 3YS
Tel 01723 583227