


Installation and Users Instructions



Model: E116S Fireplace Mantel

For use with E112RML – 2KW Electric Fire

PLEASE READ THIS MANUAL BEFORE INSTALLING AND USING THE APPLIANCE.

INSTALLER: DO NOT DISCARD THIS MANUAL – LEAVE WITH THE CUSTOMER



SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Appliance Development Services Ltd

Tel 01723 583227

SECTION 1 DIMENSIONS


Dimensions in mm



SECTION 2 ASSEMBLY AND INSTALLATION

2.1 Unpack

- Open the package carefully and remove all pieces. Carefully inspect each part for any damage before you begin assembly.
- Make sure that you have all the parts listed below before assembling.



No.	Name	Quantity
A	Top panel	1
B	Front top panel	1
C	Side panel	2
D	Right front panel	1
E	Left second panel	1
F	Right second panel	1
G	Second top panel	1
H	Base panel	1
I	Left front panel	1
J	M6x12 screws 	43
K	M6x25 screws 	14
L	Φ8x30 dowels 	17
M	Flat bracket 	3
N	Small bracket 	20
O	Washers 	14
P	Rubber feet 	6

NOTE: left and right of product are distinguished by its front view.

2.2 Before installation

Tools required: magnetic phillips screwdriver




2.3 Installation


NOTE!

- Assembly required by two adults.
- This fireplace suite must be fitted to the wall. Wall fixings are supplied with this mantel, but any other suitable concealed fixing may be used.
- Use manual screwdriver only.
- Use washer when fixing with screws. Do not overtighten bolts.
- Do not use other types or models of screws, to prevent any screws that are too long causing damage to mantels.
- To prevent scratching the mantel, only fit the fire from the back of the fireplace.


Step 1:




Step 2:




Step 3:




Step 4:




Step 5:




Step 6:




Step 7:




Step 8:




Step 9:




Step 10:




Step 11:




Step 12:




Step 13:



Step 14:



Step 15:



SECTION 3 CLEANING & MAINTAINENCE

- 1 Your fireplace mantel surface coating will give off a slight smell for a short period of time. Try to ventilate as much as possible during this time.
- 2 Daily cleaning: Clean the mantel surfaces with a soft, lint-free cloth. Do not use cleaning or polishing products and try to avoid heavy or sharp articles which may damage the surface.
- 3 Avoid long-term direct sunlight, and excessive temperatures and humidity to protect the life of your furniture surface.

Appliance Development Services Ltd

Bakers Court, Hopper Hill Road, Scarborough, N. Yorkshire. YO11 3YS
Tel 01723 583227